

## Cooking

1. Turn the rotary knob to the left to call up automatic menu mode. Turn the rotary knob to select the appropriate automatic menu for your food.
2. Confirm your selection by pressing the rotary knob/the Start/quick start button.
3. Turn the rotary knob to set the weight, and then confirm this by pressing the rotary knob/the Start/quick start button.

**i Note:** "Pizza" automatic programme (A-05): Before setting the weight you must select whether you want to prepare deep-frozen pizza (programme "P-01"), refrigerated pizza (programme "P-02") or fresh pizza (programme "quote P-03"). After confirming the selected programme by pressing the Start / quick start button you can set the weight as usual.

Display	Symbol	Food	Adjustable weight	Turn over after...
A-01		Beef	200 - 1400 g	2/3 of the time
A-02		Pork	200 - 1400 g	2/3 of the time
A-03		Poultry	400 - 1400 g	2/3 of the time
A-04		Fish	200 - 1200 g	2/3 of the time
A-05		Pizza	P1 (deep-frozen pizza) 150 - 450 g P2 (refrigerated pizza) 150 - 450 g P3 (fresh pizza) 150 - 450 g	-
A-06		Fruit/ vegetables	100 - 1000 g	-
A-07		Potatoes	100 - 800 g	-
A-08		Warming	300 - 700 g	-
A-09		Beverages	200 - 500 ml	-
A-10		Entrees	300 / 500 g	-
A-11		Defrosting by weight	-	-
A-12		Defrosting by time	-	-

## Defrosting by weight/automatic programme A-11

1. Turn the rotary knob anticlockwise until "A-11" appears in the display and  flashes, then press the rotary knob/the Start/quick start button.
2. Now select the food to be defrosted by turning the rotary knob.
3. When the required food is shown in the display, turn the rotary knob/the Start/quick start button and set the required weight by turning the rotary knob.
4. When the required weight appears in the display, press the rotary knob/the Start/quick start button. The appliance calculates the defrosting time required automatically.

Automatic programme A-11 "defrosting by weight"			
Display	Symbol	Food	Adjustable weight
d-01		Beef	100 - 1800 g
d-02		Pork	100 - 1800 g
d-03		Poultry	100 - 1800 g
d-04		Fish	100 - 1800 g
d-05		Pizza	100 - 900 g
d-06		Fruit/ vegetables	100 - 900 g
d-07		Potatoes	100 - 900 g

## Further display abbreviations

- Note:** The % information is based on the proportion of the corresponding cooking time.  
 Example: the cooking time for a "C 1" combination process takes 10 minutes. Of this, 3 minutes (30%) is provided by the microwave function and 7 minutes (70%) by the "top heat" grill function.

Grill combinations:

- "C 1" for combination 1 microwave function (30%) and "top heat" grill function (70%)  
- "C 2" for combination 2 microwave function (55%) and "top heat" grill function (45%)  
- "C 3" for combination 3 microwave function (30%) and "top and bottom heat" grill function (70%)  
- "C 4" for combination 4 microwave function (55%) and "top and bottom heat" grill function (45%)  

Grill functions:

- "Gr 1" for top heat 
- "Gr 2" for bottom heat 
- "Gr 3" for top and bottom heat 